



## BOOM PIPE RACK

Designed, tested, and certified by Skyjack

Designed to make it easier for plumbers, electricians and maintenance workers to carry pipes or conduit at height without sacrificing work space. The pipe rack is rail mounted on the front of the platform making it convenient for loading and unloading materials.

	Articulating Booms				Telescopic Booms					
Use only on listed models	SJ30 AJE* (S/N 90 000 001+)	SJ30 ARJE* (S/N 90 000 001+)	SJ46 AJ (S/N 95 000 750+)	SJ63 AJ (S/N 95 000 001+)	SJ40 T (S/N 98 001 047+)	SJ45 T (S/N 98 001 047+)	SJ61 T (S/N 97 000 806+)	SJ66 T (S/N 97 000 806+)	SJ82 T (S/N 97 100 001+)	SJ86 T (S/N 97 100 001+)
Part number	148559				162052					
Rated work load on pipe rack	235 lb (107 kg)									
Total rated work load including load on pipe rack	485 lb (220 kg) 1 Person									
Maximum wind speed	28 mph (12.5 m/s)									

Please note: Maximum allowable pipe length is 23 ft. (7 m) by 4 in. (10 cm) diameter

\*Require adapter kit 207399 in order to use option

Having equipment with features and functions that allow you and your customers to do more is a vital part of a rental company's utilization equation. Skyjack offers a range of accessory products to further expand a given product's adaptability and your power to offer a truly flexible rental choice. Accessoryzers™ is a Skyjack brand which covers factory certified attachments, options and accessories. These are developed, designed, and tested to provide increases in productivity, improved working conditions and minimal manual work.

## TELESCOPIC / ARTICULATING BOOM LIFTS

### ACCESSORIES

- Pipe rack
- Platform work lights
- Glazier kit
- Tool caddy

### OPTIONS

- Airline to platform
- Hydraulic generator
- Hydraulic oil cooler
- Flashing light
- Side or rear gate entry
- Secondary guarding – electrical or mechanical
- Bio oil
- Lifting lugs
- Lockable control box cover
- Auxiliary top rail
- Non destructive testing
- Extended warranties
- Welder package
- Welder ready
- Platform size options

### PACKAGE OPTIONS

- Hostile environment package
- Cold weather start kit
- Arctic weather package
- Positive air shut off valve
- Tire options



Please note: Standard lead times may be increased when optional equipment is added, consult factory. Capacities and machine weights may differ when options are added.

#### Skyjack Head Office

55 Campbell Rd.  
Guelph, ON Canada N1H 1B9  
Sales Inquiries: 1-877-755-4387 (1-877-SJLIFTS)  
Main Switchboard: 1-800-265-2738  
Phone: 519-837-0888  
Fax: 519-837-8104  
Email: [skyjack@skyjack.com](mailto:skyjack@skyjack.com)

#### Skyjack Parts & Service

3451 Swenson Ave.  
St. Charles, IL 60174 USA  
Phone: 630-262-0005  
Toll Free: 1-800-275-9522  
Fax: 630-262-0006  
Email: [service@skyjack.com](mailto:service@skyjack.com)

[www.skyjack.com](http://www.skyjack.com)

This brochure is for illustrative purpose only and based on the latest information at the time of printing. Skyjack Inc. reserves the right to make changes at any time, without notice, to specifications, standard and optional equipment. Consult the Operating Maintenance and Parts Manuals for proper procedures.