

BOOM PIPE RACK

The boom pipe rack is designed to optimize platform work space and make it easier for plumbers, electricians and maintenance workers to carry pipes and conduit


- Adjustable nylon strap to secure loads
- Mounting location eases loading/unloading material without impeding work space
- Rated work load up to 107 kg
- Maximum allowable pipe length is 7 m by 10 cm diameter





BOOM PIPE RACK

KEY FEATURES



Use only on listed models	ARTICULATING BOOMS				TELESCOPIC BOOMS		
Model	SJ30 ARJE*	SJ45 AJ+ SJ46 AJ SJ51 AJ	SJ60 AJ+ SJ63 AJ	SJ85 AJ	SJ45 T SJ45 T+	SJ66 T SJ66 T+	SJ86 T
Serial number range	90000001+ A300000001+	A301100001+ B301100001+ 95000001+ B301000001+	A302100001+ B302100001+ 95300001+	95400001+ A303000001+	980001+ 98000001+ A400000001+	97000001+ A401000001+	97100001+ A402000001+
Rated load on pipe rack				107 kg			
Overall weight (unloaded)	8.8 kg			6.8 kg			
Maximum wind speed				12.5 m/s			

Please note: Standard lead times may be increased when optional equipment is added, consult factory Capacities and machine weights may differ when options are added Maximum allowable pipe length is 7 m x 10 cm diameter *Require adapter kit 207399 in order to use option

SKYJACK AUSTRALIA, PTY LTD

Unit 1, 35 Honeycomb Drive Eastern Creek, NSW 2766 Australia Tel: +61 (0) 2 9854 0700 Email: ausoffice@skyjack.com

