

## Skyjack's ECOSTART reduces emissions, limits noise and saves fuel.

It is conservatively estimated that an engine can be left running for several hours during a typical working day.

This idle-eliminating system automatically turns off the engine if no function has been selected, within 3 minutes. Once activated, a blue LED light will illuminate to alert the operator that the engine needs to be restarted—simply restart by pressing the switch located next to the light.

### Benefits include:

- Reduced emissions
- Lower fuel costs
- Less jobsite noise
- Decreased maintenance and longer service intervals
- Less engine/machine hours improves residual value, increasing ROI



#### AVAILABLE MODELS\*

SJ45 AJ+

SJ60 AJ+

SJ45 T+

SJ6826 RT

SJ6832 RT

SJ9233 RT

SJ9243 RT

SJ9253 RT

SJ9664 RT

\* Not suitable for Stage V engines with DPf

More details are available via your local Skyjack Product support representative – ask for document 236002

**Phone:** +44 (0) 1691 678 030

**Fax:** +44 (0) 1691 676 238

**Service Email:** [service@skyjackeurope.co.uk](mailto:service@skyjackeurope.co.uk)

#### Skyjack UK

Unit 1, Maes-y-Clawdd  
Maesbury Road Industrial Estate  
Oswestry, Shropshire, SY10 8NN  
Tel: +44 1691 676235  
Fax: +44 1691 676239  
Email: [info@skyjackeurope.co.uk](mailto:info@skyjackeurope.co.uk)

#### Skyjack SAS (France)

74 Rue Sibert  
F-42400 Saint Chamond  
France  
Tel: +33 (0) 4 78 73 53 32  
Fax: +33 (0) 4 78 56 52 42

#### Skyjack Hebebühnen GmbH (Germany)

Därmanbusch 2a  
D-58456 Witten  
Tel: +49 (0) 2302 20 26 909  
Fax: +49 (0) 2302 20 25 671

#### Skyjack AB (Sweden)

Agnesbergsvägen 28  
424 38 Agnesberg  
Sweden  
Tel: +46 (0) 31 21 22 45  
Fax: +46 (0) 31 787 65 10

**SKYJACK**  
simply reliable