

**ECOTRAY** prevents potential leaks from Hydraulic systems dripping onto floors and other internal components. The Skyjack system removes the need for a cumbersome, unsightly "nappy" and is particularly suited for working on sensitive areas, such as decorative flooring, clean rooms and areas where hygiene and concern for chemical contamination are a priority. Unlike other systems that focus on the main hydraulic tray, **ECOTRAY** also protects against leaks from drive motors and steering cylinders.

# Skyjack's **ECOTRAY** has been designed with essential machine functionality in mind.

## These essential functions include:

- Pothole protection
- Static strap use
- Access to the emergency stop
- Emergency lowering
- Base controls





SKY






# VERTICAL MAST LIFTS

# DC SCISSOR LIFTS

## **E SERIES DC SCISSOR LIFTS\***



# **KEY FEATURES**

- Protects against the whole hydraulic system, not just the main hydraulic tray.
- Avoids cumbersome "nappy" attachment
- Prioritises machine functionality
- Protected from jobsite debris damage, forklift handling, etc.
- Available as a factory fit or field install option (SKYCODED<sup>™</sup> specifications only)
- Installed in less than 10 minutes
- Absorbent pads changed in seconds
- ECOTRAY label identifies Eco-friendly option fitted

#### \*Illustrative purposes only; tray arrangement varies between E Series models

### Skyjack UK

Unit 1, Maes-y-Clawdd Maesbury Road Industrial Estate Oswestry, Shropshire, SY10 8NN Tel: +44 1691 676235 Fax: +44 1691 676239 Email: info@skyjackeurope.co.uk Skyjack SAS (France) 74 Rue Sibert F-42400 Saint Chamond France Tel: +33 (0) 4 78 73 53 32 Fax: +33 (0) 4 78 56 52 42

#### Skyjack Hebebühnen GmbH (Germany) Därmannsbusch 2a D-58456 Witten Tel: +49 (0) 2302 20 26 909 Fax: +49 (0) 2302 20 25 671

Skyjack AB (Sweden) Agnesbergsvägen 28 424 38 Agnesberg Sweden Tel: +46 (0) 31 21 22 45 Fax: +46 (0) 31 787 65 10



This brochure is for illustrative purposes only and based on the latest information at the time of printing. Skyjack Inc. reserves the right to make changes at any time, without notice, to specifications, standard and optional equipment. Consult the Operating Maintenance and Parts Manuals for proper procedures.

# **COMPATIBLE MODELS**

SJ12 E	$\checkmark$
SJ16 E	$\checkmark$
SJ20 E	$\checkmark$
SJ3215 & SJ3215 E	$\checkmark$
SJ3219 & SJ3219 E	$\checkmark$
SJ3220 E	$\checkmark$
SJ3226 & SJ3226 E	$\checkmark$
SJ4726 & SJ4726 E	$\checkmark$
SJ4732 & SJ4732 E	$\checkmark$
SJ4740 & SJ4740 E	$\checkmark$