


ECOTRAY prevents potential leaks from Hydraulic systems dripping onto floors and other internal components. The Skyjack system removes the need for a cumbersome, unsightly “nappy” and is particularly suited for working on sensitive areas, such as decorative flooring, clean rooms and areas where hygiene and concern for chemical contamination are a priority. Unlike other systems that focus on the main hydraulic tray, **ECOTRAY** also protects against leaks from drive motors and steering cylinders.

Skyjack’s **ECOTRAY** has been designed with essential machine functionality in mind.


These essential functions include:

- Pothole protection
- Static strap use
- Access to the emergency stop
- Emergency lowering
- Base controls



VERTICAL MAST LIFTS

DC SCISSOR LIFTS



KEY FEATURES

- Protects against the whole hydraulic system, not just the main hydraulic tray.
- Avoids cumbersome “nappy” attachment
- Prioritises machine functionality
- Protected from jobsite debris damage, forklift handling, etc.
- Available as a factory fit or field install option (SKYCODED™ specifications only)
- Installed in less than 10 minutes
- Absorbent pads changed in seconds
- **ECOTRAY** label identifies Eco-friendly option fitted

COMPATIBLE MODELS

SJ12 E	✓
SJ16 E	✓
SJ20 E	✓
SJ3215	✓
SJ3219	✓
SJ3220	✗
SJ3226	✓
SJ4720	✓
SJ4726	✓
SJ4732	✓
SJ4740	✓

Skyjack UK

Unit 1, Maes-y-Clawdd
Maesbury Road Industrial Estate
Oswestry, Shropshire, SY10 8NN
Tel: +44 1691 676235
Fax: +44 1691 676239
Email: info@skyjackeurope.co.uk

Skyjack SAS (France)

74 Rue Sibert
F-42400 Saint Chamond
France
Tel: +33 (0) 4 78 73 53 32
Fax: +33 (0) 4 78 56 52 42

Skyjack Hebebühnen GmbH (Germany)

Därmanbusch 2a
D-58456 Witten
Tel: +49 (0) 2302 20 26 909
Fax: +49 (0) 2302 20 25 671

Skyjack AB (Sweden)

Agnesbergsvägen 28
424 38 Agnesberg
Sweden
Tel: +46 (0) 31 21 22 45
Fax: +46 (0) 31 787 65 10

ACCESSORYZERS
www.skyjack.com/accessoryzers