

LANYARDGO

ENSURES HARNESS COMPLIANCE ON SKYJACK BOOMS

Falls from height continue to be a leading cause of fatality during boom operation.

To ensure the operator is wearing a safety harness, Skyjack's LanyardGO inhibits the lift & drive functions from the machines platform until their lanyard has been safely attached. Once the lanyard is attached within the LanyardGO system, the platform controls become operational.

The LanyardGO system uses a proximity sensor to detect the lanyard position and is electronically integrated into the platform controls.



KEY FEATURES

- Simple and easy to use
- No need for a specialized harness or lanyard
- Visual indicators at upper control box and on the LanyardGO box:
 - Red when lanyard is not detected
 - Green when lanyard is detected
- Compatible with steel and aluminum lanyards
- IP67 sensor enclosed in sealed enclosure
- Compatible with all current and legacy Skyjack boom models
- Available as a direct factory installation or aftermarket accessory

Skyjack Head Office

55 Campbell Rd.
Guelph, ON Canada N1H 1B9
Sales Inquiries: 1-877-755-4387 (1-877-SJLIFTS)
Main Switchboard: 1-800-265-2738
Phone: 519-837-0888
Fax: 519-837-8104
Email: skyjack@skyjack.com

Skyjack Parts & Service

2525 Enterprise Circle
West Chicago, IL 60185 USA
Phone: 630-262-0005
Toll Free: 1-800-275-9522
Fax: 630-262-0006
Email: service@skyjack.com

SKYJACK
simply reliable™

www.skyjack.com/accessoryzers