

TILT SWITCH LOCATIONS

Skyjack Vertical Mast Lifts, Compact and Conventional Electric Scissor Lifts, and Boom Lifts are equipped with a Tilt Switch as standard equipment. Use the information below to locate the Tilt Switch on the equipment listed.




Vertical Mast - Tilt Switch

For Vertical Mast Lifts - SJ12 and SJ16 models, the Tilt Switch is located on a bracket at the base of the unit between the battery pack and the steer cylinder.



SJIII - Tilt Switch

For SJIII Compact and Conventional models, the Tilt Switch is located on the base frame to the right of the base control panel.



Boom - Tilt Switch

For Boom models, the Tilt Switch is mounted inside the base control console. Check the parts manual for your model of vertical mast, scissor, or boom lift to identify the correct Tilt Switch part number, as well as where it's mounted on the machine. Please consult the manuals online at www.skyjack.com, or contact product support at 1-800-275-9522 if you have any questions.

