



## SECONDARY GUARDING

Designed, tested, and certified by Skyjack

Skyjack offers two distinct “secondary guarding” systems, one electronic and one mechanical. This option allows the equipment user to select, following a job specific risk assessment, the most appropriate solution for any particular need or application. Both the electrical and mechanical options can be ordered with new Skyjack booms or installed on equipment already in service.

Availability	Models		
Telescopic Booms	SJ45 T	SJ66 T	SJ86 T
Articulating Booms	SJ46 AJ	SJ51 AJ	SJ63 AJ

# SECONDARY GUARDING

## KEY FEATURES



### SECONDARY GUARDING – SGE - ELECTRICAL

The Skyjack SGE system features a sensor bar that, when pushed, instantly stops all functions and initiates an audible siren and high intensity flashing beacon. If the bar is released within one second the siren and beacon will cease and the selected function will return. If pressure is applied for more than one second the siren and beacon will continue to activate and the engine will stop, halting all functions until reset. The applicable emergency controls can still be operated to bring the platform down to ground safely. If the system is accidentally activated by the operator, it can be easily reset using the illuminated push button on the control box.

- Suitable for use on all Skyjack booms (2006 and later).
- Does not limit or restrict normal use.
- No moving parts, minimal maintenance required.



### SECONDARY GUARDING – SGM – MECHANICAL

The Skyjack SGM system features a protective steel structure that is designed to reduce the possibility of the operator being held against the controls in the event of unintended contact with an obstruction. The system does not impair operator visibility, mobility on the platform or access to the work area.

- Suitable for use on all Skyjack booms (2006 and later).
- Easily installed by bolting directly to the platform without need for any modifications.
- Low weight (21kg) minimizes platform capacity reductions.
- Fleet flexibility - transferable between machines.



Please note: Standard lead times may be increased when optional equipment is added, consult factory. Capacities and machine weights may differ when options are added.

[www.skyjack.com](http://www.skyjack.com)

**Skyjack Australia Pty Ltd**  
4 Coates Place  
Wetherill Park  
New South Wales, 2164  
Tel: +61 (0) 2878 63200  
Fax: +61 (0) 2878 63222  
Email: [jcranmer@skyjack.com](mailto:jcranmer@skyjack.com)

This brochure is for illustrative purpose only and based on the latest information at the time of printing. Skyjack Inc. reserves the right to make changes at any time, without notice, to specifications, standard and optional equipment. Consult the Operating Maintenance and Parts Manuals for proper procedures.

AU/NZ/03/2016